JRiver Media Player

We suggest use JRiver MediaCenter in Windows system.
Download and purchase the software from http://www.jriver.com/

JRiver Media Center 19

Tools -> Options -> Audio Device -> TUSBAudio ASIO Driver[ASIO]

Options -> Settings -> DSP & output format

Output Encoding -> DSD in DoP format(reuires DSD capable DAC)

Done.